


# SCAN SHEET FOR WELCH ALLYN 3800 SERIES CCD-HEX

This scan sheet is for ALL WorkFlows **ESC to close DISABLED**: Preamble 27 66 : Post amble 27 68 and Preference, Desktop, Windows and UN-Check "USE ESC" for closing window.  
WHEN SCANNING BARCODES IN WORKFLOWS, **CAPLOCKS CAN BE ON OR OFF**

3800LR/LX DEFAULT

#1



WORKFLOWS SETUP

#2



**The barcodes below are for use with the Hands Free Stand (option)**



**Automatic trigger:** The scanner scans continuously at full power

AUTOMATIC TRIGGER



**Presentation Mode:** The LEDs are off until a bar code is presented to the scanner. Then the LEDs turn on automatically to read the bar code. Presentation Modes use normal office light to detect the bar code.

PRESENTATION MODE



**Barcode Depot**



• 138 CATHERINE DRIVE • OWENS CROSS ROADS • AL • 35763 •

• 866-556-5766 • 877-572-6642 • [kimbrent@barcode-depot.com](mailto:kimbrent@barcode-depot.com) •